

THE COMPARATIVE STATEMENT OF VEHICLE MAINTENANCE & SPARE PARTTS FOR THE FY 2024-25													
Sl no	Item Decription	Unit	Druk Penden Engineering										
			SKY JACKER TATA 712	BOLERO	SKY JACKER (710BS6)	WATER TANKER [TATA 1010	TATA TIPPER (16.15)	WATER TANKER(T ATA 11.09)	FARM TACTOR (FARMTR	VACCUM TANKER (TATA	VACCUM TANKER (TATA 709)	VACUUM TANKER - EICHER	DCM TRUCK (SML)
(I)	Engine Parts												
1	Engine Oil	Litre	395	395	395	395	395	395	395	395	395	395	395
2	Oil/Mobile Filter	Each	1750	240	1950	1750	1950	1750	950	1750	1750	1750	1150
3	Fuel/Disel Filter	Each	2400	165	2400	2400	2400	2400	495	2400	2400	2400	1400
4	Water Saparator	Each	1450	165	1450	1450	1450	1450	800	1450	1450	1450	1100
5	Engine head gasket	Each	4900	1400	4900	4900	4900	4900	2500	4900	4900	4900	2900
6	Fuel pump Assy	Each	18500	85000	185000	185000	185000	185000	165000	185000	185000	185000	190000
7	Fuel injection overflow pipe	Each	1400	650	1400	1400	1400	1400	1100	1400	1400	1400	1250
8	Fuel pump washer	Each	10	20	10	10	10	10	10	10	10	10	10
9	Feed pump Assy	Each	1950	2800	1950	1950	1950	1950	1650	1950	1950	1950	2800
10	Fuel injector pipe	Each	2200	950	2200	2200	2200	2200	1200	2200	2200	2200	1250
11	Fuel injector nozzel	Each	6000	5500	6000	6000	6000	6000	3900	6000	6000	6000	6000
12	Timing belt	Each	2500	1800	2500	2500	2500	2500	0	2500	2500	2500	2500
13	Timing cover	Each	850	1950	850	850	850	850	0	850	850	850	850
14	Timing cover gear	Each	2500	1900	2500	2500	2500	2500	0	2500	2500	2500	2500
15	Fan belt	Each	950	350	950	950	950	950	350	950	950	950	950
16	Timing cover oil seal	Each	340	150	340	340	340	340	450	340	340	340	340
17	Tappid cover packing	Each	350	75	350	350	350	350	150	350	350	350	350
18	Piston set	Set	14000	6500	14000	14000	14000	14000	7000	14000	14000	14000	14000
19	Piston ring set	Set	9500	4200	9500	9500	9500	9500	6000	9500	9500	950	9500
20	Rocker Arm	Each	800	1800	800	800	800	800	850	800	800	800	800
21	Rocker shaft Assy	Each	6500	4500	6500	6500	6500	6500	1100	6500	6500	6500	6500
22	Puppet valve	Each	650	850	650	650	650	650	1400	650	650	650	650
23	Valve guide	Each	400	950	400	400	400	400	1100	400	400	400	400
24	Valve seat	Each	250	700	250	250	250	250	850	250	250	250	250
25	Valve key	Each	75	400	75	75	75	75	400	75	75	75	75
26	Valve spring Inner/Outer	Each	700	1600	700	700	700	700	650	700	700	700	900
27	Valve washer	Each	50	300	50	50	50	50	200	50	50	50	50
28	Connecting bearing STD	Set	2900	1250	2900	2900	2900	2900	1650	2900	2900	2900	2900
29	Main bearing STD	Set	2400	1450	2400	2400	2400	2400	1900	2400	2400	2400	2400
30	Connecting bush	Each	400	150	400	400	400	400	800	400	400	400	400
31	Connecting rod	Each	6500	2700	6500	6500	6500	6500	3500	6500	6500	6500	6500
32	Liner Set (STD)	Set	6500	2500	6500	6500	6500	6500	4500	6500	6500	6500	6500
33	Thrust washer (STD)	Each	450	150	450	450	450	450	900	450	450	450	450
34	Benjo washer	Each	1	2	1	1	1	1	2	1	1	1	1
35	Cam shaft	Each	9500	9000	9500	9500	9500	9500	7000	9500	9500	9500	9500
36	Cam shaft bush	Each	450	850	450	450	950	450	950	450	450	450	450
37	Cam shaft gear	Each	3200	1800	3200	3200	3200	3200	3000	3500	3200	3200	3200
38	Crank shaft	Each	48000	19500	48000	48000	48000	48000	18000	48000	48000	48000	48000
39	Crank shaft oil seal	Each	1200	900	1200	1200	1200	1200	950	1200	1200	1200	1200
40	Bearing 6302	Each	450	650	450	450	450	450	550	450	450	450	450
41	Bearing 6202	Each	340	650	340	340	340	340	550	340	340	340	340

THE COMPARATIVE STATEMENT OF VEHICLE MAINTENANCE & SPARE PARTTS FOR THE FY 2024-25													
Sl no	Item Decription	Unit	Druk Penden Engineering										
			SKY JACKER TATA 712	BOLERO	SKY JACKER (710BS6)	WATER TANKER [TATA 1010	TATA TIPPER (16.15)	WATER TANKER(T ATA 11.09)	FARM TACTOR (FARMTR	VACCUM TANKER (TATA	VACCUM TANKER (TATA 709)	VACUUM TANKER - EICHER	DCM TRUCK (SML)
42	Drain plug	Each	200	80	200	200	200	200	100	200	200	200	200
43	Tensiner Assy	Each	2800	1800	2800	2800	2800	2800	0	2800	2800	2800	2800
44	Baby Filter	Each	290	140	290	290	380	290	0	290	290	290	290
(II)	<b>Transmission Parts</b>	<b>NA</b>											
1	Gear Oil	Letter	395	395	395	395	395	395	395	395	395	395	395
2	Fly Wheel Bearing	Each	650	950	650	650	650	650	800	650	650	650	650
3	Fly wheel	Each	14500	4900	9500	14500	16500	14500	7400	14500	14500	14500	9500
4	Fly wheel ring	Each	3500	2500	4500	3500	4500	3500	3500	3500	3500	3500	4500
5	Clutch plate (Round Tyre)	Each	7400	3500	6800	7400	7400	7400	2800	7400	7400	7400	6800
6	Clutch plate (Fan Tyre)	Each	9000	4800	8900	9000	9000	9000	9500	900	9000	9000	5900
7	Pressure plate	Each	11500	6500	12560	11500	14000	11500	8000	11500	11500	11500	12500
8	Master cylinder	Each	4800	2500	3500	4800	4800	4800	4000	4800	4800	4800	3500
9	Master cylinder kit	Each	900	950	900	900	900	900	650	900	900	900	900
10	Clutch cylinder Assy	Each	1950	950	1750	1950	1950	1950	1800	1950	1950	1950	1750
11	Clutch cylinder (Upper)	Each	2200	950	1750	2200	2200	2200	1800	2200	2200	2200	1750
12	Clutch cylinder (lower)	Each	2400	950	1750	2400	2400	2400	1800	2400	2400	2400	1750
13	Clutch cylinder kit	Set	350	250	450	350	350	350	700	350	3500	350	450
14	Gear box packing	Each	190	140	190	190	190	190	180	190	190	190	190
15	Gear box oil seal	Each	240	85	240	240	240	240	250	240	240	240	240
16	Gear pinion shaft	Each	2700	4200	2700	2700	2700	2700	3500	2700	2700	2700	2700
17	Top shaft bearing	Each	1100	1100	1100	1100	1100	1100	1200	1100	1100	1100	1100
18	Relese bearing	Each	2400	1450	2400	2400	2400	2400	2700	2400	2400	2400	2400
19	Relese bearing fork	Each	800	550	800	800	800	800	850	800	800	800	800
20	Relese bearing lock	Each	150	80	150	150	150	150	150	150	150	150	150
21	Jetting gear pinion	Each	4500	2200	4500	4500	4500	4500	0	4500	4500	4500	4500
22	Cross bearing	Each	1450	950	1650	1450	1450	1450	0	1550	1450	1450	1650
23	Cross holder	Each	1200	800	1800	1200	1200	1200	0	1200	1200	1200	1800
24	Center bearing Assy	Set	1150	850	1650	1150	1150	1150	0	1150	1150	1150	1650
25	Propeller shaft Nut & Bolt	Each	25	25	25	25	25	25	0	25	25	25	25
26	Center Baring Cushion Rubber	Each	450	350	950	450	450	450	0	450	450	450	950
27	Center Bearing	Each	700	700	1650	700	700	700	0	700	700	700	1650
28	Yoke & Teeth Assy	Set	4800	2200	4800	4800	4800	4800	0	4800	4800	4800	4800
29	Clutch relese bearing	Each	2400	1450	2400	2400	2400	2400	2400	2400	2400	2400	2400
30	1st Gear	Each	3500	2800	3500	3500	3500	3500	4500	3500	3500	3500	3500
31	2nd Gear	Each	3400	3500	3400	3400	3400	3400	3800	3400	3400	3400	3400
32	3rd Gear	Each	4200	1700	4200	4200	4200	4200	3500	4200	4200	4200	4200
33	4th Gear	Each	3700	1450	3700	3700	3700	3700	3400	3700	3700	3700	3700
34	5th Gear	Each	3500	1300	3500	3500	3500	3500	3200	3500	3500	3500	3500
35	Reverse Gear	Each	2900	1250	2900	2900	2900	2900	3200	2900	2900	2900	2900
36	Top Shaft	Each	5200	3500	5200	5200	5200	5200	4200	5200	5200	5200	5200
37	Snap Ring set	Set	450	350	450	450	450	450	3500	450	450	450	450

THE COMPARATIVE STATEMENT OF VEHICLE MAINTENANCE & SPARE PARTTS FOR THE FY 2024-25													
Sl no	Item Decription	Unit	Druk Penden Engineering										
			SKY JACKER TATA 712	BOLERO	SKY JACKER (710BS6)	WATER TANKER [TATA 1010	TATA TIPPER (16.15)	WATER TANKER(T ATA 11.09)	FARM TACTOR (FARMTR	VACCUM TANKER (TATA	VACCUM TANKER (TATA 709)	VACUUM TANKER - EICHER	DCM TRUCK (SML)
38	Main Shaft	Each	4800	3400	4800	4800	4800	4800	6400	4800	4800	4800	4800
39	Mainshaft Gear	Each	3900	3500	3900	3900	3900	3900	4400	3900	3900	3900	3900
40	Synchronizer Ring	Each	2200	950	2200	2200	2200	2200	3200	2200	2200	2200	2200
41	Gear MainShaft Reverse	Each	3500	1700	3500	3500	3500	3500	3500	3500	3500	3500	3500
42	Niddle Bearing Mainshaft Reverse	Each	850	750	850	850	850	850	900	850	850	850	850
43	Gear Assy Main Shaft 2nd	Each	4400	1300	4400	4400	4400	4400	4000	4400	4400	4400	4400
44	Shaft Reverse Gear	Each	850	600	850	850	850	850	900	850	850	850	850
45	Fork Gear Shift	Each	3200	1900	3200	3200	3200	3200	3500	3200	3200	3200	3200
46	Shift Gear Cable	Each	5900	1850	5900	5900	5900	5900	0	5900	5900	5900	5900
47	Select Gear Cable	Each	4500	1450	4500	4500	4500	4500	0	4500	4500	4500	4500
48	Gear Lever Assy	Each	8000	1900	8000	8000	8000	8000	8000	8000	8000	8000	8000
(III)	<b>REAR AXLE (Differential) Parts</b>	<b>NA</b>											
1	Differential Carrier SET	Set	140000	28000	140000	140000	140000	140000	35000	140000	140000	140000	185000
2	Spider Cross	Each	1800	950	1800	1800	1800	1800	3200	1800	1800	1800	1850
3	Differential Gear	Each	1900	1400	1900	1900	1900	1900	6500	1900	1900	1900	1900
4	Spacer Diff Gear	Each	1250	450	1250	1250	1250	1250	1400	1250	1250	1250	1250
5	Pinion Differential	Each	1450	950	1450	1450	1450	1450	4000	1450	1450	1450	1450
6	Spacer Pinion Diff Gear	Each	1450	1800	1450	1450	1450	1450	0	1450	1450	1450	1450
7	Pinion Pilot Bearing Inner	Each	2200	650	2200	2200	2200	2200	2800	2200	2250	2200	2200
8	Pinion Pilot Bearing Outer	Each	1850	750	1850	1850	1850	1850	2800	1850	1850	1850	1850
9	Tail Pinion Oil Seal	Each	950	120	950	950	950	950	0	950	950	950	950
10	Taper Roller Bearing	Each	900	800	900	900	900	900	0	900	900	900	900
11	Front Hub Oil Seal Inner	Each	190	95	220	190	190	190	280	190	190	190	220
12	Front Hub Oil Seal Outer	Each	190	80	220	190	190	190	280	190	190	190	220
13	Rear Hub Oil Seal Inner	Each	240	95	280	240	240	240	450	240	240	240	280
14	Rear Hub Oil Seal Outer	Each	240	80	280	240	240	240	450	240	240	240	280
15	Front Spacer Bearing	Each	950	800	1200	950	950	950	900	950	950	950	1200
16	Front Hub Wheel Bearing Inner	Each	1250	950	1250	1250	1250	1250	1250	1250	1250	1250	1250
17	Front Hub Wheel Bearing Outer	Each	800	750	1100	800	800	800	800	800	800	800	1100
18	Front Wheel Check Nut	Each	140	80	160	140	140	140	160	140	190	140	160
19	Front Hub Assy	Each	9500	4500	9500	9500	9500	9500	6500	9500	9500	9500	6500
20	Front Break Drum	Each	11800	3500	11800	11800	11800	11800	0	11800	11800	11800	5800
21	Front Wheel Drum	Each	8000	4900	8000	8000	8000	8000	0	8000	8000	8000	4500
22	Tie Rod End assy	Each	6500	750	6500	6500	6500	6500	3800	6500	6500	6500	3500
23	Tie Rod End Kit	Each	1450	700	1650	1450	1450	1450	900	1450	1450	1450	1800
24	King Pin SET	Set	5500	0	5500	5500	5500	5500	700	5500	5500	5500	4900
25	Rear Hub Bearing Spacer	Each	650	350	650	650	650	650	850	650	650	650	850
26	Rear Hub Bearing Inner	Each	2200	950	2200	2200	2200	2200	1600	2200	2200	2200	1140
27	Rear Hun Bearing Outer	Each	1850	800	1850	1850	1850	1850	1400	1850	1850	1850	1140
28	Rear Hub Assy	Each	9500	3200	9500	9500	9500	9500	8500	9500	9500	9500	6500
29	Rear Outer wheel Spacer	Each	900	450	900	900	900	900	0	900	900	900	900

THE COMPARATIVE STATEMENT OF VEHICLE MAINTENANCE & SPARE PARTTS FOR THE FY 2024-25													
Sl no	Item Decription	Unit	Druk Penden Engineering										
			SKY JACKER TATA 712	BOLERO	SKY JACKER (710BS6)	WATER TANKER [TATA 1010	TATA TIPPER (16.15)	WATER TANKER(T ATA 11.09)	FARM TACTOR (FARMTR	VACCUM TANKER (TATA	VACCUM TANKER (TATA 709)	VACUUM TANKER - EICHER	DCM TRUCK (SML)
30	Lock Nut Rear Wheel	Each	50	75	50	50	50	50	250	50	50	50	50
31	Washer Lock Rear Wheel	Each	90	50	90	90	90	90	100	90	90	90	90
32	Rear Breather Pipe	Each	700	650	700	700	700	700	0	700	700	700	700
33	Differential Oil	Letter	395	395	395	395	395	395	395	395	395	395	395
34	Grease	KG	600	600	600	600	600	600	600	600	600	600	600
(IV)	Steering System Parts	NA											
1	Steering Column	Each	4500	3500	4500	4500		4500	4500	4500	4500	4500	5800
2	Steering upper Column	Each	2200	2500	2200	2200	4500	2200	1500	2200	2200	2200	3500
3	Steering Column Bracket	Each	6500	950	6500	6500	2200	6500	2500	6500	6500	6500	2900
4	Steering Column Assy	Each	14000	3900	14000	14000	6500	14000	4500	14000	14000	14000	5800
5	Pipe Assy Pressure	Each	1500	450	1500	1500	14000	1500	500	1500	1500	1500	1500
6	Pipe Assy Return	Each	8000	450	8000	8000	8000	8000	800	8000	8000	8000	8000
7	Pipe Assy Return Reservior	Each	9500	450	9500	9500	9500	9500	0	9500	9500	9500	9500
8	Pipe Assy Suction	Each	9500	450	9500	9500	9500	9500	0	9500	9500	9500	9500
9	Pitman Arm Power Steering	Each	6500	1850	6500	6500	6500	6500	0	6500	6500	6500	6500
10	Power Steering Box Assy	Each	75000	14800	75000	75000	75000	75000	0	75000	75000	75000	75000
11	Pulley Pump Power Steering	Each	2200	1500	2200	2200	2200	2200	0	2200	2200	2200	2200
12	Power Steering Pump Pulley	Each	2200	1500	2200	2200	2200	2200	0	2200	2200	2200	2200
13	V-Belt Power Steering Pump	Each	8500	6500	8500	8500	8500	8500	0	8500	8500	8500	8500
14	Pump Vane Power Steering(ZF)	Each	9500	7500	9400	9400	9400	9400	0	9400	4900	9400	9400
15	Braket Power Steering Pump	Each	4700	2900	4700	4700	4700	4700	0	4700	4700	4700	4700
16	Braket Pump Adjustment	Each	850	350	850	850	850	850	0	850	850	850	850
17	Power Steering Reserver Assy	Each	950	850	950	950	950	950	0	950	950	950	950
18	Power Steering Oil Filter	Letter	650	390	650	650	650	650	0	650	650	650	650
19	Power Steering Oil Tank	Each	1450	850	1450	1450	1450	1450	0	1450	1450	1450	850
20	Power Steering Oil Cap	Each	180	190	180	180	180	180	0	180	180	180	180
21	Steering Cover Right Side	Each	950	550	950	950	950	950	0	950	950	950	950
22	Steering Cover Left Side	Each	950	550	950	950	950	950	0	950	950	950	950
23	Steering Dust Cover	Each	450	190	450	450	450	450	0	450	450	450	450
(V)	Suspension Parts	NA											
1	Front Center Bolt	Each	175	45	160	175	190	175	0	175	175	175	160
2	Front Spring Bush	Each	200	95	200	200	210	200	0	200	200	200	200
3	Front U Bolt & Nut	Each	950	190	980	950	1200	950	0	950	950	950	980
4	Front Spring Pin	Each	280	150	280	280	290	280	0	280	280	280	280
5	Cycle Pin	Each	280	185	280	280	290	280	0	280	280	280	280
6	Front Main Leaf	Each	3500	2400	3500	3500	3500	3500	0	3500	3500	3500	3500
7	Front 2nd Leaf	Each	3500	2400	3500	3500	3500	3500	0	3500	3500	3500	3500
8	Front 3rd Leaf	Each	3200	2200	3200	3200	3200	3200	0	3200	3200	3200	3200
9	Front 4th Leaf	Each	2200	2100	2200	2200	2200	2200	0	2200	2200	2200	2200
10	Front 5th Leaf	Each	2900	2000	2900	2900	2900	2900	0	2900	2900	2900	2900
11	Front 6th Leaf	Each	2700	1800	2700	2700	2700	2700	0	2700	2700	2700	2700
12	Front 7th Leaf	Each	1950	1800	1950	1950	1950	1950	0	1950	1950	1950	1950

THE COMPARATIVE STATEMENT OF VEHICLE MAINTENANCE & SPARE PARTTS FOR THE FY 2024-25													
Sl no	Item Decription	Unit	Druk Penden Engineering										
			SKY JACKER TATA 712	BOLERO	SKY JACKER (710BS6)	WATER TANKER [TATA 1010	TATA TIPPER (16.15)	WATER TANKER(T ATA 11.09)	FARM TACTOR (FARMTR	VACCUM TANKER (TATA	VACCUM TANKER (TATA 709)	VACUUM TANKER - EICHER	DCM TRUCK (SML)
13	Soft Suspension Spring Lower	Each	950	2900	950	950	950	950	0	950	950	950	950
14	Rear Main Leaf	Each	4500	2400	4500	4500	4500	4500	0	4500	4500	4500	4500
15	Rear 2nd Leaf	Each	4500	2400	4500	4500	4500	4500	0	4500	4500	4000	4500
16	Rear 3rd Leaf	Each	4200	2200	4200	4200	4200	4200	0	4200	4200	4200	4200
17	Rear 4th Leaf	Each	3900	2100	3900	3900	3900	3900	0	3900	3900	3900	3900
18	Rear 5th Leaf	Each	3800	2000	3800	3800	3800	3800	0	3800	3800	3800	3800
19	Rear 6th Leaft	Each	3500	1800	3500	3500	3500	3500	0	3500	3500	3500	3500
20	Shock Absorber Front	Each	5800	2200	5800	5800	4800	5800	0	3800	5800	3800	4800
21	Shock Absorber Bush Lower	Each	75	50	75	75	75	75	0	75	75	75	75
22	Shock Absorber Bush upper	Each	75	50	75	75	75	75	0	75	75	75	75
23	Rear Helper Spring 1st Leaf	Each	3200	950	3200	3200	3200	3200	0	3200	3200	3200	3200
24	Rear Helper Spring 2nd Leaf	Each	3100	900	3100	3100	3100	3100	0	3100	3100	3100	3100
25	Rear Helper Spring 3rd Leaf	Each	3000	800	3000	3000	3000	3000	0	3000	3000	3000	3000
26	Rear Helper Spring 4th Leaf	Each	2800	750	2800	2800	2800	2800	0	2800	2800	2800	2800
27	Rear Helper Spring 5th Leaf	Each	2700	600	2700	2700	2700	2700	0	2700	2700	2700	2700
28	Rear Helper Spring 6th Leaf	Each	2500	500	2500	2500	2500	2500	0	2500	2500	2500	2500
29	Rear Helper Spring 7th Leaf	Each	2400	500	2400	2400	2400	2400	0	2400	2400	2400	2400
30	Rear Center Bolt & Nut	Each	110	45	110	110	110	110	0	110	110	110	110
31	Rear U Bolt & Nut	Each	950	190	980	950	950	950	0	950	950	950	980
32	Rear Spring Pin	Each	390	140	390	390	390	390	0	390	390	390	390
33	Rear Spring Bush	Each	250	140	250	250	250	250	0	250	250	250	250
34	Rear Spring Bump Stopper	Each	850	175	850	850	850	850	0	350	850	850	850
35	Rear Spring Hanger	Each	1850	850	1850	1850	1850	1850	0	1850	1850	1850	1850
36	Rear Spring Bracket Helper	Each	950	450	950	950	950	950	0	950	950	950	950
(VI)	Cooling System Parts	NA											
1	Radiator Assy	Each	14500	9500	14500	14500	16500	14500	7500	14500	14500	14500	13500
2	Radiator Shroud	Each	3500	950	3500	3500	4500	3500	2500	3500	3500	3500	5800
3	Upper Radiator Hose Pipe	Each	450	1700	450	450	450	450	350	450	450	450	450
4	Lower Radiator Hose Pipe	Each	500	950	500	500	500	500	380	500	500	500	500
5	Coolent Reservior Tant Assy	Each	1200	950	1200	1200	1200	1200	0	1200	1200	1200	1200
6	Coolent Reservior Tank Cap	Each	140	450	140	140	140	140	0	140	140	140	140
7	Viscous Fan	Each	1800	90	1800	1800	1800	1800	1600	1800	1800	1800	1800
8	Viscous Clutch	Each	1400	1400	1400	1400	1400	1400	0	1400	1400	1400	1400
9	Water Pump Assy	Each	5800	3500	5800	5800	6800	5800	4000	5800	5800	5800	5800
10	Water Pump O-Ring	Each	150	190	150	150	150	150	150	150	150	150	150
11	Spacer Fan	Each	4200	400	4200	4200	4200	4200	1600	4200	4200	4200	4200
12	Water Pump Pulley	Each	950	700	950	950	1050	950	1200	950	950	950	950
13	Thermostat Case	Each	1200	650	1200	1200	1200	1200	0	1200	1200	1200	1200
14	Thermostat Cover	Each	350	400	350	350	350	350	0	350	350	350	350
15	Thermostat Assy	Each	1250	950	1250	1250	1250	1250	150	1250	1250	1250	1250
16	Radiator Cap	Each	350	150	350	350	350	350	150	350	350	350	350
17	Thermostat Case Gasket	Each	100	40	100	100	100	100	0	100	100	100	100

THE COMPARATIVE STATEMENT OF VEHICLE MAINTENANCE & SPARE PARTTS FOR THE FY 2024-25													
Sl no	Item Decription	Unit	Druk Penden Engineering										
			SKY JACKER TATA 712	BOLERO	SKY JACKER (710BS6)	WATER TANKER [TATA 1010	TATA TIPPER (16.15)	WATER TANKER(T ATA 11.09)	FARM TACTOR (FARMTR	VACCUM TANKER (TATA	VACCUM TANKER (TATA 709)	VACUUM TANKER - EICHER	DCM TRUCK (SML)
18	Thermostat Spacer	Each	450	150	450	450	450	450	0	450	450	450	450
(VII)	<b>Break System</b>	<b>NA</b>											
1	Front Break Lining Set	Each	3800	1200	3200	3200	3200	3800	0	3800	3800	3800	3200
2	Front Break Cam Spring	Each	250	80	250	250	250	250	0	250	250	250	250
3	Front Break Return Spring	Each	450	80	450	450	450	450	0	450	450	450	450
4	Front Break Bush Kit	Each	900	150	90	90	90	90	0	90	90	900	90
5	Front Break Shoe Assy	Each	3200	1200	2500	3200	3200	3200	0	3200	3200	3200	2500
6	Rear Break Lining Set	Each	3800	950	3200	3800	3200	3800	1800	3800	3800	3800	3200
7	Rear Break Cam Spring	Each	250	80	250	250	250	250	800	250	250	250	250
8	Rear Breas Return Spring	Each	450	80	450	450	450	450	400	450	450	450	450
9	Rear Break Bush Kit	Each	900	150	90	90	90	90	0	90	90	90	90
10	Rear Break Shoe Assy	Each	3400	4900	3400	3400	3400	3400	2500	3400	3400	3400	3400
11	Front Auto Slack Adjuster	Each	5400	290	5400	5400	5400	5400	0	5400	5400	5400	5400
12	Rear Auto Slack Adjuster	Each	5400	290	5400	5400	5400	5400	0	5400	5400	5400	5400
13	Front MSP Repair Kit	Set	1900	650	1900	1900	1900	1900	0	1900	1900	1900	1900
14	Front Break Actuator Assy	Each	2800	2900	2800	2800	2800	2800	0	2800	2800	2800	2800
15	Rear MSP Repair Kit	Set	1450	650	1450	1450	1450	1450	0	1450	1450	1450	1450
16	Rear Break Actuator Assy	Each	2800	2900	2800	2800	2800	2800	0	2800	2800	2800	2800
17	Front Outlet Pipe	Each	750	390	750	750	750	750	0	750	750	750	750
18	Front Break Hose Pipe	Each	900	400	900	900	900	900	0	900	900	900	900
19	Pipe Assy Actuator Inletparking	Each	1400	650	1400	1400	1400	1400	0	1400	1400	1400	1400
20	Pipe Assy Actuator Inletservice	Each	800	650	800	800	800	800	0	800	800	800	800
21	Air Reservoir Tank Assy	Each	14000	0	14000	14000	14000	14000	0	14000	14000	14000	14000
22	Hand Control Valve	Each	6500	0	6500	6500	6500	6500	0	6500	6500	6500	6500
23	DDU Assy	Each	19500	0	19500	19500	19500	19500	0	19500	19500	19500	11000
24	DDU Kit	Set	4500	0	4500	4500	4500	4500	0	4500	4500	4500	800
25	DDU Pipe 1 Inlet	Each	850	0	850	850	850	850	0	850	850	850	800
26	DDU Pipe 2 Inlet	Each	850	0	850	850	850	850	0	850	850	850	800
27	DDU Pipe 3 Inlet	Each	850	0	850	850	850	850	0	850	850	850	800
28	Dual Break Valve Assy	Each	8500	0	8500	8500	8500	8500	0	850	850	8500	7000
29	Dual Break Valve Pipe FR Inlet	Each	750	0	750	750	750	750	0	750	750	750	750
30	Dual Break Valve Pipe FR Outlet	Each	750	0	750	750	750	750	0	750	750	750	750
31	Dual Break Valve Pipe RR Outlet	Each	750	0	750	750	750	750	0	750	750	750	750
32	Dual Break Valve Pipe RR Inlet	Each	750	0	750	750	750	750	0	750	750	750	750
33	Exhaust Break Assy	Each	5800	0	5800	5800	5800	5800	0	5800	5800	5800	5800
34	Exhaust Break Pipe	Each	900	0	900	900	900	900	0	900	900	900	900
(VIII)	<b>Inlet &amp; Exhaust System</b>	<b>NA</b>											
1	Air Filter Assy	Each	3200	950	3900	3200	3200	3200	700	3200	3200	3200	3900
2	Snorkel Assy	Each	4500	1900	4500	4500	4500	4500	0	4500	4500	4500	4500
3	Bellow Air Intake Hose	Each	1450	650	1450	1450	1450	1450	0	1450	1450	1450	1450
4	Hose Air Cleaner Outer	Each	2800	400	2800	2800	2800	2800	0	2800	2800	2800	2800
5	Air Cleaner Outlet Hose Assy	Each	1800	400	1800	1800	1800	1800	0	1800	1800	1800	1800

THE COMPARATIVE STATEMENT OF VEHICLE MAINTENANCE & SPARE PARTTS FOR THE FY 2024-25													
Sl no	Item Decription	Unit	Druk Penden Engineering										
			SKY JACKER TATA 712	BOLERO	SKY JACKER (710BS6)	WATER TANKER [TATA 1010	TATA TIPPER (16.15)	WATER TANKER(T ATA 11.09)	FARM TACTOR (FARMTR	VACCUM TANKER (TATA	VACCUM TANKER (TATA 709)	VACUUM TANKER - EICHER	DCM TRUCK (SML)
6	Air Intake Duct Assy	Each	2800	0	2800	2800	2800	2800	0	2800	2800	2800	2800
7	Intake Manifold Packing	Each	90	150	90	90	90	90	150	90	90	90	90
8	Intake Manifold Assy	Each	7000	3500	7000	7000	7000	7000	4200	7000	7000	7000	7000
9	Turbo Charger Assy	Each	34500	18500	34500	34500	38000	34500	0	34500	34500	34500	34500
10	Turbo Charger Packing	Each	250	150	250	250	250	250	0	250	250	250	250
11	Turbo Pipe Oil Supply	Each	650	700	650	650	650	650	0	650	650	650	650
12	Intercooler Assy	Each	13000	12000	13000	13000	16000	13000	0	13000	13000	13000	13000
13	Intercooler Pipe	Each	750	700	750	750	850	750	0	750	750	750	750
14	Hose TC Out	Each	650	700	650	650	650	650	0	650	650	650	650
15	Intercooler Hose Out	Each	850	700	850	850	850	850	0	850	850	850	850
16	Intercooler Hose Inlet	Each	850	700	850	850	850	850	0	850	850	850	850
17	Exhaust Center Pipe Assy	Each	1200	800	1200	1200	1200	1200	0	1200	1200	1200	1200
18	Exhaust Pipe Front	Each	800	950	800	800	800	800	0	800	800	800	800
19	Exhaust DCO Assy	Each	18000	1900	18000	18000	18000	18000	0	18000	18000	18000	18000
20	Exhaust Gasket	Each	450	40	450	450	450	450	0	450	4500	450	450
21	DOC Gasket	Each	200	40	200	200	200	200	0	200	200	200	200
22	Exhaust Muffler Assy	Each	7500	3900	7500	7500	7500	7500	3800	7500	7500	7500	7500
23	Exhaust Tail Pipe Assy	Each	1900	750	1900	1900	2800	1900	0	1900	1900	1900	1900
24	Compressor Assy	Each	3800	2900	3800	3800	3800	3800	0	3800	3800	3800	3800
25	Compressor Gasket	Each	180	150	180	180	180	180	0	180	180	180	180
26	Compressor Major Kit	Each	1200	950	1200	1200	1200	1200	0	1200	1200	1200	1200
27	Compressor Minor Kit	Each	900	550	900	900	900	900	0	900	900	900	900
28	Compressor Piston	Each	1800	900	1800	1800	1800	1800	0	1800	1800	1800	1800
29	Compressor Piston Ring Set (STD)	Each	950	400	950	950	950	950	0	950	950	950	950
30	Compressor Outlet Pipe Assy	Each	700	750	700	700	700	700	0	700	700	700	700
31	Compressor Hose Air Inlet	Each	800	450	800	800	800	800	0	800	800	800	800
(IX)	<b>Fuel System Parts</b>	<b>NA</b>											
1	Fuel Injection Pump Assy	Each	290000	145000	290000	290000	290000	290000	85000	290000	290000	290000	290000
2	Flange Plate Assy	Each	4800	8000	4800	4800	4800	4800	0	4800	4800	4800	4800
3	Pump Gear	Each	4500	3400	4500	4500	4500	4500	3900	4500	4500	4500	4500
4	O-Ring	Each	90	100	90	90	90	90	100	90	90	90	90
5	Feed Pump Assy	Each	3400	2800	3400	3400	3400	3400	1900	3400	3400	3400	3400
6	Injection Pipe	Each	1800	750	1800	1800	1800	1800	950	1800	1800	1800	1800
7	Fuel Return Pipe	Each	1400	900	1400	1400	1400	1400	0	1400	1400	1400	1400
8	Over Flow Hose Pipe	Each	650	75	650	650	650	650	0	650	650	650	650
9	Over Flow Pipe	Each	250	150	250	250	250	250	0	250	250	250	250
10	FIP Fuel Pipe Assy	Each	1800	1200	1800	1800	1800	1800	850	1800	1800	1800	1800
11	Nozzle & Holder Assy	Each	7500	800	7500	7500	7500	7500	4500	7500	7500	7500	7500
12	Bridge Nozzle	Each	5800	6500	5800	5800	5800	5800	0	5800	5800	5800	5800
13	Fuel Tank Assy	Each	14000	3900	14000	14000	14000	14000	3500	14000	14000	14000	8500
14	Band Fuel Tank	Each	6200	3900	6200	6200	6200	6200	0	6200	6200	6200	5000

THE COMPARATIVE STATEMENT OF VEHICLE MAINTENANCE & SPARE PARTTS FOR THE FY 2024-25													
Sl no	Item Decription	Unit	Druk Penden Engineering										
			SKY JACKER TATA 712	BOLERO	SKY JACKER (710BS6)	WATER TANKER [TATA 1010	TATA TIPPER (16.15)	WATER TANKER(T ATA 11.09)	FARM TACTOR (FARMTR	VACCUM TANKER (TATA	VACCUM TANKER (TATA 709)	VACUUM TANKER - EICHER	DCM TRUCK (SML)
15	Water Saparator Assy (Plastic Type)	Each	1650	0	1650	1650	1650	1650	0	1650	1650	1650	1650
16	Fuel Pipe Over Flow	Each	950	150	950	950	950	950	0	950	950	950	950
17	Fuel Filter Pipe Inlet	Each	650	250	650	650	650	650	0	650	650	650	650
18	Fuel Filter Pipe Assy Out	Each	1400	250	1400	1400	1400	1400	0	1400	1400	1500	1400
(X)	<b>Accelerator System Parts</b>	<b>NA</b>											
1	Accelerator Pedal Assy	Each	1850	850	1900	1850	1850	1850	1800	1850	1850	1850	1900
2	Accelerator Cable	Each	1800	590	1650	1800	1800	1800	950	1800	1800	1800	1650
3	Accelerator Pedal Arm Assy	Each	900	590	900	900	900	900	1800	900	900	900	900
4	Accelerator Control Bush	Each	600	200	600	600	600	600	650	600	600	600	600
(XI)	<b>Electrical System Parts</b>	<b>NA</b>											
1	Battery terminal end	Each	75	75	75	75	75	75	95	95	75	75	75
2	Battery cable +ive	Each	800	450	800	800	800	800	800	800	800	800	800
3	Battery cable -ive	Each	800	450	800	800	800	800	800	800	800	800	800
4	Self bush 12V	Each	80	90	80	80	80	80	90	80	80	80	80
5	Self carbon 12V	Each	850	450	850	850	850	850	450	850	850	850	850
6	Self top cover	Each	2800	1800	2800	2800	2800	2800	2900	2800	2800	2800	2800
7	Self field coil 12v	Each	2400	1700	2400	2400	2400	2400	3200	2400	2400	2400	2400
8	Self housing	Each	4500	2300	4500	4500	4500	4500	3900	4500	4500	4500	4500
9	Carbon rocker 12v	Each	950	850	950	950	980	950	2500	950	950	950	950
10	Carbon holder	Each	850	650	850	850	950	850	950	850	850	850	850
11	Rectifier	Each	1600	900	1600	1600	1600	1600	800	1600	1600	1600	1600
12	Carbon bush 12 v	Each	650	190	650	650	650	650	450	650	650	650	650
13	Solonoid switch 12v	Each	1950	1700	1950	1950	1950	1950	1900	1950	1950	1950	1950
14	Alternator Assy	Each	8900	7500	8900	8900	8900	8900	5500	8900	8900	8900	9500
15	Alternator carbon bush	Each	150	185	150	150	150	150	190	150	150	150	150
16	Alternator cut out	Each	900	950	900	900	900	900	680	900	900	900	900
17	Dynamo bearing	Each	350	450	350	350	350	350	290	350	350	350	650
18	Rotor coil	Each	1800	2300	1800	1800	1800	1800	1800	1800	1800	1800	2800
19	Bendix pinion	Each	950	850	950	950	950	950	1150	950	950	950	1400
20	Self Armerture 12v	Each	4800	3800	4800	4800	5500	4800	3900	4800	4800	4800	3900
21	Starte coil	Each	650	1200	650	650	1650	650	2800	650	650	650	650
22	Ignition switch	Set	3500	2950	3500	3500	4500	3500	950	3500	3500	3500	3800
23	Starter relay 12v	Each	450	350	450	450	450	450	350	450	450	450	450
24	Relay 5 pin 12v	Each	350	400	350	350	350	350	450	350	350	350	350
25	Relay 4 pin 12v	Each	400	180	400	400	400	400	350	400	400	400	400
26	Relay 3 pin 12v	Each	350	250	350	350	350	350	250	350	350	350	350
27	Relay 2 pin 12v	Each	350	1400	350	350	350	350	250	350	350	350	350
28	Electric horn 2v	Each	1400	3900	1400	1400	1400	1400	1400	1400	1400	1400	1400
29	Musical horn 12v	Each	2950	3900	2950	2950	2950	2950	0	2950	2950	2950	2950
30	Horn Assy	Each	1450	250	1450	1450	1450	1450	1400	1450	1450	1450	1450
31	Horn relay	Each	390	20	390	390	390	390	350	390	390	390	390







THE COMPARATIVE STATEMENT OF VEHICLE MAINTENANCE & SPARE PARTTS FOR THE FY 2024-25													
Sl no	Item Decription	Unit	Druk Penden Engineering										
			SKY JACKER TATA 712	BOLERO	SKY JACKER (710BS6)	WATER TANKER [TATA 1010	TATA TIPPER (16.15)	WATER TANKER(T ATA 11.09)	FARM TACTOR (FARMTR	VACCUM TANKER (TATA	VACCUM TANKER (TATA 709)	VACUUM TANKER - EICHER	DCM TRUCK (SML)
11	Fuel injection overflow pipe Replace	Each	300	300	300	300	300	300	500	300	300	300	300
12	Fuel injector pipe Replace	Each	300	300	300	300	300	300	500	300	300	300	300
13	Fuel injector nozzel Repair/Replace	Each	6000	4900	6000	6000	6000	6000	500	6000	6000	6000	6000
14	Timing belt Replace	Each	300	800	300	300	300	300	0	300	300	300	300
15	Timing cover Replace	Each	1500	800	1500	1500	1500	1500	0	1500	1500	1500	1500
16	Timing cover gear Replace	Each	1500	1500	1500	1500	1500	1500	0	1500	1500	1500	1500
17	Fan belt Replace	Each	300	200	300	300	300	300	300	300	300	300	300
18	Timing cover oil seal Replace	Each	1500	1500	1500	1500	1500	1500	1000	1500	1500	1500	1500
19	Tappid cover packing Replace	Each	800	500	800	800	800	800	500	800	800	800	800
20	Rocker Arm Replace	Each	2000	1500	2000	2000	2000	2000	1000	2000	2000	2000	2100
21	Rocker shaft Assy Replace	Each	2000	1500	2000	2000	2000	2000	1000	2000	2000	2000	2000
22	Puppet valve Replace	Each	6000	1500	6000	6000	6000	6000	1000	6000	6000	6000	6000
23	Liner Set (STD) Replace	Each	6000	1500	6000	6000	6000	6000	3500	6000	6000	6000	6000
24	Benjo washer Replace	Each	20	20	20	20	20	20	20	20	20	20	20
25	Cam shaft Replace	Each	9000	4000	9000	9000	9000	9000	3000	900	9000	9000	9000
26	Cam shaft bush Replace	Each	9000	4000	9000	9000	9000	9000	2500	900	9000	9000	9000
27	Cam shaft gear Replace	Each	6000	2500	6000	6000	6000	6000	2500	6000	6000	6000	6000
28	Crank shaft Replace	Each	9000	10000	9000	9000	9000	9000	4000	9000	9000	1000	9000
29	Crank shaft oil seal Replace	Each	4500	4000	4500	4500	4500	4500	1500	4500	4500	4500	4500
30	Bearing 6302 Replace	Each	3500	1500	3500	3500	3500	3500	500	3500	3500	3500	3500
31	Bearing 6202 Replace	Each	3500	1500	3500	3500	3500	3500	500	3500	3500	3500	3500
32	Drain plug Replace	Each	150	50	150	150	150	150	50	150	150	1500	150
33	Tensiner Assy Replace	Each	800	1500	800	800	800	800	0	800	800	800	800
34	Baby Filter Replace	Each	100	100	100	100	100	100	0	100	100	100	100
(XV)	Engine	NA											
1	Gear Box Overhauling	Each	4500	3000	4500	4500	4500	4500	6000	4500	4500	4500	4500
2	Gear Oil Replace	Each	200	200	200	200	200	200	500	200	200	200	200
3	Fly Wheel Bearing Replace	Each	1500	2500	1500	1500	1500	1500	4000	1500	1500	1500	1500
4	Fly wheel Replace	Each	1500	2500	1500	1500	1500	1500	4000	1500	1500	1500	1500
5	Fly wheel ring Replace	Each	1500	2500	1500	1500	1500	1500	4000	1500	1500	1500	1500
6	Clutch plate/Pressure Plate Replace	Each	4000	2500	4000	4000	4000	4000	5000	4000	4000	4000	4000
7	Master cylinder Replace	Each	1000	850	1000	1000	1000	1000	1500	1000	1000	1000	1000
8	Master cylinder kit Replace	Each	1000	850	1000	1000	1000	1000	1000	1000	1000	1000	1000
9	Clutch cylinder Assy Replace	Each	300	500	300	300	300	300	0	300	300	300	300
10	Clutch cylinder (Upper) Replace	Each	300	500	300	300	300	300	0	300	300	300	300
11	Clutch cylinder (lower) Replace	Each	300	500	300	300	300	300	0	300	300	300	300
12	Clutch cylinder kit Replace	Each	1000	500	1000	1000	1000	1000	0	1000	1000	1000	1000
13	Gear box packing Replace	Each	1000	1000	1000	1000	1000	1000	1500	1000	1000	1000	1000
14	Gear box oil seal Replace	Each	1000	800	1000	1000	1000	1000	3000	1000	1000	1000	1000

THE COMPARATIVE STATEMENT OF VEHICLE MAINTENANCE & SPARE PARTTS FOR THE FY 2024-25													
Sl no	Item Decription	Unit	Druk Penden Engineering										
			SKY JACKER TATA 712	BOLERO	SKY JACKER (710BS6)	WATER TANKER [TATA 1010	TATA TIPPER (16.15)	WATER TANKER(T ATA 11.09)	FARM TACTOR (FARMTR	VACCUM TANKER (TATA	VACCUM TANKER (TATA 709)	VACUUM TANKER - EICHER	DCM TRUCK (SML)
15	Gear pinion shaft Replace	Each	4500	1500	4500	4500	4500	4500	8000	4500	4500	4500	4500
16	Top shaft bearing Replace	Each	4500	1500	4500	4500	4500	4500	8000	4500	4500	4500	4500
17	Relese bearing Replace	Each	2000	1500	2000	2000	2000	2000	4000	2000	2000	2000	2000
18	Relese bearing fork Replace	Each	2000	1500	2000	2000	2000	2000	4000	2000	2000	2000	2000
19	Relese bearing lock Replace	Each	1500	1500	1500	1500	1500	1500	4000	1500	1500	1500	1500
20	Jetting gear pinion Replace	Each	4500	4500	4500	4500	4500	4500	0	4500	4500	4500	4500
21	Cross bearing Replace	Each	600	600	600	600	600	600	0	600	600	600	600
22	Cross holder Replace	Each	600	600	600	600	600	600	0	600	600	600	600
23	Center bearing Assy Replace	Each	600	600	600	600	600	600	0	600	600	600	600
24	Propeller shaft Nut & Bolt Replace	Each	20	20	20	20	20	20	0	20	20	20	20
25	Center Baring Cushion Rubber Replace	Each	600	600	600	600	600	600	0	600	600	600	600
26	Center Bearing Replace	Each	600	600	600	600	600	600	0	600	600	600	600
27	Yoke & Teeth Assy Replace	Each	2500	1800	2500	2500	2500	2500	0	2500	2500	2500	2500
28	Clutch relese bearing Replace	Each	1500	1500	1500	1500	1500	1500	4000	1500	1500	1500	1500
29	1st Gear Replace	Each	4500	3000	4500	4500	4500	4500	8000	4500	4500	4500	4500
30	2nd Gear Replace	Each	4500	3000	4500	4500	4500	4500	8000	4500	4500	4500	4500
31	3rd Gear Replace	Each	4500	3000	4500	4500	4500	4500	8000	4500	4500	4500	4500
32	4th Gear Replace	Each	4500	3000	4500	4500	4500	4500	8000	4500	4500	4500	4500
33	5th Gear Replace	Each	4500	3000	4500	4500	4500	4500	8000	4500	4500	4500	4500
34	Reverse Gear Replace	Each	4500	3000	4500	4500	4500	4500	8000	4500	4500	4500	4500
35	Top Shaft Replace	Each	4500	3000	4500	4500	4500	4500	8000	4500	4500	4500	4500
36	Main Shaft Replace	Each	4500	3000	4500	4500	4500	4500	8000	4500	4500	4500	4500
37	Mainshaft Gear Replace	Each	4500	3000	4500	4500	4500	4500	8000	4500	4500	4500	4500
38	Synchronizer Ring Replace	Each	4500	3000	4500	4500	4500	4500	8000	4500	4500	4500	4500
39	Gear MainShaft Reverse Replace	Each	4500	3000	4500	4500	4500	4500	8000	4500	4500	4500	4500
40	Niddle Bearing Mainshaft Reverse Replace	Each	4500	3000	4500	4500	4500	4500	8000	4500	4500	4500	4500
41	Gear Assy Main Shaft 2nd Replace	Each	4500	3000	4500	4500	4500	4500	8000	4500	4500	4500	4500
42	Shaft Reverse Gear Replace	Each	4500	3000	4500	4500	4500	4500	8000	4500	4500	4500	4500
43	Fork Gear Shift Replace	Each	4500	3000	4500	4500	4500	4500	8000	4500	4500	4500	4500
44	Shift Gear Cable Replace	Each	4500	700	4500	4500	4500	4500	8000	4500	4500	4500	4500
45	Select Gear Cable Replace	Each	4500	700	4500	4500	4500	4500	8000	4500	4500	4500	4500
46	Gear Lever Assy Replace	Each	4500	1000	4500	4500	4500	4500	3000	4500	4500	4500	4500
(XVI)	<b>REAR AXLE (Differential)</b>	<b>NA</b>											
1	Differential Assy Overhauling	Each	4000	3000	4000	4000	4000	4000	7000	4000	4000	4000	4000
2	Differential Carrier SET Replace	Each	4000	2000	4000	4000	4000	4000	7000	4000	4000	4000	4000
3	Spider Cross Replace	Each	4000	3000	4000	4000	4000	4000	7000	4000	4000	4000	4000
4	Differential Gear Replace	Each	4000	3000	4000	4000	4000	4000	7000	4000	4000	4000	4000
5	Spacer Diff Gear Replace	Each	4000	3000	4000	4000	4000	4000	7000	4000	4000	4000	4000
6	Pinion Differential Replace	Each	4000	3000	4000	4000	4000	4000	7000	4000	4000	4000	4000

THE COMPARATIVE STATEMENT OF VEHICLE MAINTENANCE & SPARE PARTTS FOR THE FY 2024-25													
Sl no	Item Decription	Unit	Druk Penden Engineering										
			SKY JACKER TATA 712	BOLERO	SKY JACKER (710BS6)	WATER TANKER [TATA 1010	TATA TIPPER (16.15)	WATER TANKER(T ATA 11.09)	FARM TACTOR (FARMTR	VACCUM TANKER (TATA	VACCUM TANKER (TATA 709)	VACUUM TANKER - EICHER	DCM TRUCK (SML)
7	Spacer Pinion Diff Gear Replace	Each	4000	3000	4000	4000	4000	4000	7000	4000	4000	4000	4000
8	Pinion Pilot Bearing Inner Replace	Each	4000	3000	4000	4000	4000	4000	7000	4000	4000	4000	4000
9	Pinion Pilot Bearing Outer Replace	Each	4000	850	4000	4000	4000	4000	7000	4000	4000	4000	4000
10	Tail Pinion Oil Seal Replace	Each	800	800	800	800	800	800	0	800	800	800	800
11	Taper Roller Bearing Replace	Each	1500	3000	1500	1500	1500	1500	0	1500	1500	1500	1500
12	Front Hub Greassing	Each	500	300	500	500	500	500	500	500	500	500	500
13	Rear Hub Greassing	Each	500	300	500	500	500	500	0	500	500	500	500
14	Front Spacer Bearing Replace	Each	500	300	500	500	500	500	500	500	500	500	500
15	Front Hub Wheel Bearing Inner Change	Each	500	300	500	500	500	500	500	500	500	500	500
16	Front Hub Wheel Bearing Outer Change	Each	500	300	500	500	500	500	500	500	500	500	500
17	Front Wheel Check Nut Change	Each	500	300	500	500	500	500	100	500	500	500	500
18	Front Hub Assy Replace	Each	500	300	500	500	500	500	500	500	500	500	500
19	Front Break Drum Replace	Each	500	300	500	500	500	500	0	500	500	500	500
20	Front Wheel Drum Replace	Each	500	300	500	500	500	500	0	500	500	500	500
21	Tie Rod End assy Replace	Each	800	600	800	800	800	800	1500	800	800	800	800
22	Tie Rod End Kit Change	Each	600	600	600	600	600	600	1500	600	600	600	600
23	King Pin SET Change	Each	3000	0	3000	3000	3000	3000	3000	3000	3000	3000	3000
24	Rear Hub Bearing Spacer Change	Each	500	300	500	500	500	500	0	500	500	300	500
25	Rear Hub Bearing Inner Replace	Each	500	300	500	500	500	500	0	500	500	500	500
26	Rear Hun Bearing Outer Replace	Each	500	300	500	500	500	500	0	500	500	500	500
27	Rear Hub Assy Replace	Each	500	300	500	500	500	500	0	500	500	500	500
28	Rear Outer wheel Spacer Change	Each	500	300	500	500	500	500	0	500	500	500	500
29	Lock Nut Rear Wheel Change	Each	500	300	500	500	500	500	0	500	500	500	500
30	Washer Lock Rear Wheel Change	Each	500	300	500	500	500	500	0	500	500	500	500
31	Rear Breather Pipe Change	Each	400	300	400	400	400	400	0	400	400	400	400
(XVII)	Steering System	NA											
1	Steering Column Change	Each	800	1000	800	800	800	800	1500	800	800	800	800
2	Steering upper Column Change	Each	800	1000	800	800	800	800	1500	800	800	800	800
3	Steering Column Bracket Change	Each	800	1000	800	800	800	800	800	800	800	800	800
4	Steering Column Assy Replace	Each	800	1000	800	800	800	800	1500	800	800	800	800
5	Pipe Assy Pressure Replace	Each	800	300	800	800	800	800	1000	800	800	800	800
6	Pipe Assy Return Replace	Each	800	300	800	800	800	800	1000	800	800	800	800
7	Pipe Assy Return Reservior Replace	Each	800	300	800	800	800	800	0	800	800	800	800
8	Pipe Assy Suction Change	Each	1500	1500	1500	1500	1500	1500	0	1500	1500	1500	1500
9	Pitman Arm Power Steering Replace	Each	800	1500	800	800	800	800	0	800	800	800	800
10	Power Steering Box Assy Replace	Each	1500	1000	1500	1500	1500	1500	0	1500	1500	1500	1500

THE COMPARATIVE STATEMENT OF VEHICLE MAINTENANCE & SPARE PARTTS FOR THE FY 2024-25													
Sl no	Item Decription	Unit	Druk Penden Engineering										
			SKY JACKER TATA 712	BOLERO	SKY JACKER (710BS6)	WATER TANKER [TATA 1010	TATA TIPPER (16.15)	WATER TANKER(T ATA 11.09)	FARM TACTOR (FARMTR	VACCUM TANKER (TATA	VACCUM TANKER (TATA 709)	VACUUM TANKER - EICHER	DCM TRUCK (SML)
11	Pulley Pump Power Steering Change	Each	900	1000	900	900	900	900	0	900	900	900	900
12	Power Steering Pump Pulley Change	Each	800	1000	800	800	800	800	0	800	800	800	800
13	V-Belt Power Steering Pump Change	Each	300	1000	300	300	300	300	0	300	300	300	300
14	Pump Vane Power Steering(ZF) Replace	Each	500	1000	500	500	500	500	0	500	500	500	500
15	Braket Power Steering Pump Replace	Each	800	1000	800	800	800	800	0	800	800	800	800
16	Power Steering Reserver Assy Change	Each	300	300	300	300	300	300	0	300	300	300	300
17	Power Steering Oil Filter Change	Each	100	100	100	100	100	100	0	100	100	100	100
18	Power Steering Oil Tank Change	Each	200	300	200	200	200	200	0	200	200	200	200
19	Power Steering Oil Cap Change	Each	100	50	100	100	100	100	0	100	100	100	100
20	Steering Cover Right Side Change	Each	800	1500	800	800	800	800	0	800	800	800	800
21	Steering Cover Left Side Change	Each	800	1500	800	800	800	800	0	800	800	800	800
22	Steering Dust Cover Change	Each	100	100	100	100	100	100	0	100	100	100	100
(XVIII)	<b>Suspension</b>	<b>NA</b>											
1	Front Center Bolt Replace	Each	1500	500	1500	1500	1500	1500	0	1500	1500	1500	1500
2	Front Spring Bush Change	Each	1500	500	1500	1500	1500	1500	0	1500	1500	1500	1500
3	Front U Bolt & Nut Change	Each	300	300	300	300	300	300	0	300	300	300	300
4	Front Spring Pin Change	Each	1500	500	1500	1500	1500	1500	0	1500	1500	1500	1500
5	Cycle Pin Change	Each	1500	500	1500	1500	1500	1500	0	1500	1500	1500	1500
6	Front Main Leaf Change	Each	1500	500	1500	1500	1500	1500	0	1500	1500	1500	1500
7	Front 2nd Leaf Change	Each	1500	500	1500	1500	1500	1500	0	1500	1500	1500	1500
8	Front 3rd Leaf Change	Each	1500	500	1500	1500	1500	1500	0	1500	1500	1500	1500
9	Front 4th Leaf Change	Each	1500	500	1500	1500	1500	1500	0	1500	1500	1500	1500
10	Front 5th Leaf Change	Each	1500	500	1500	1500	1500	1500	0	1500	1500	1500	1500
11	Front 6th Leaft Change	Each	1500	500	1500	1500	1500	1500	0	1500	1500	1500	1500
12	Front 7th Leaf Change	Each	1500	500	1500	1500	1500	1500	0	1500	1500	1500	1500
13	Soft Suspension Spring Lower Change	Each	1000	1000	1000	1000	1000	1000	0	1000	1000	1000	1000
14	Rear Main Leaf Change	Each	1500	500	1500	1500	1500	1500	0	1500	1500	1500	1500
15	Rear 2nd Leaf Change	Each	1500	500	1500	1500	1500	1500	0	1500	1500	1500	1500
16	Rear 3rd Leaf Change	Each	1500	500	1500	1500	1500	1500	0	1500	1500	1500	1500
17	Rear 4th Leaf Change	Each	1500	500	1500	1500	1500	1500	0	1500	1500	1500	1500
18	Rear 5th Leaf Change	Each	1500	500	1500	1500	1500	1500	0	1500	1500	1500	1500
19	Rear 6th Leaft Change	Each	1500	500	1500	1500	1500	1500	0	1500	1500	1500	1500
20	Shock Absorber Front Replace	Each	200	200	200	200	200	200	0	200	200	200	200
21	Shock Absorber Bush Lower Change	Each	200	100	200	200	200	200	0	200	200	200	200

THE COMPARATIVE STATEMENT OF VEHICLE MAINTENANCE & SPARE PARTTS FOR THE FY 2024-25													
Sl no	Item Decription	Unit	Druk Penden Engineering										
			SKY JACKER TATA 712	BOLERO	SKY JACKER (710BS6)	WATER TANKER [TATA 1010	TATA TIPPER (16.15)	WATER TANKER(T ATA 11.09)	FARM TACTOR (FARMTR	VACCUM TANKER (TATA	VACCUM TANKER (TATA 709)	VACUUM TANKER - EICHER	DCM TRUCK (SML)
22	Shock Absorber Bush upper Change	Each	200	100	200	1500	200	200	0	200	200	200	200
23	Rear Helper Spring 1st Leaf Replace	Each	1500	500	1500	1500	1500	1500	0	1500	1500	1500	1500
24	Rear Helper Spring 2nd Leaf Replace	Each	1500	500	1500	1500	1500	1500	0	1500	1500	1500	1500
25	Rear Helper Spring 3rd Leaf Repace	Each	1500	500	1500	1500	1500	1500	0	1500	1500	1500	1500
26	Rear Helper Spring 4th Leaf Replace	Each	1500	500	1500	1500	1500	1500	0	1500	1500	1500	1500
27	Rear Helper Spring 5th Leaf Replace	Each	1500	500	1500	1500	1500	1500	0	1500	1500	1500	1500
28	Rear Helper Spring 6th Leaf Replace	Each	1500	500	1500	1500	1500	1500	0	1500	1500	1500	1500
29	Rear Helper Spring 7th Leaf Replace	Each	1500	500	1500	1500	1500	1500	0	1500	1500	1500	1500
30	Rear Center Bolt & Nut Change	Each	1500	500	1500	1500	1500	1500	0	1000	1500	1500	1500
31	Rear U Bolt & Nut Change	Each	300	300	300	300	300	300	0	100	300	300	300
32	Rear Spring Pin Change	Each	1500	500	1500	1500	1500	1500	0	1000	1500	1500	1500
33	Rear Spring Bush Change	Each	1500	500	1500	1500	1500	1500	0	1000	1500	1500	1500
34	Rear Spring Bump Stopper Change	Each	800	500	800	800	800	800	0	800	800	800	800
35	Rear Spring Hanger Replace	Each	800	500	800	800	800	800	0	800	800	800	800
36	Rear Spring Bracket Helper Replace	Each	800	500	800	800	800	800	0	800	800	800	800
(XIX)	<b>Cooling System</b>	<b>NA</b>											
1	Radiator Assy Replace	Each	1000	500	1000	1000	1000	1000	800	1000	1000	1000	1000
2	Radiator Shroud Change/Repair	Each	1000	500	1000	1000	1000	1000	1000	1000	1000	1000	1000
3	Upper Radiator Hose Pipe Change	Each	200	200	200	200	200	200	300	200	200	200	200
4	Lower Radiator Hose Pipe Change	Each	200	200	200	200	200	200	300	200	200	200	200
5	Coolent Reservior Tant Assy Replace	Each	300	200	300	300	300	300	0	300	300	300	300
6	Coolent Reservior Tank Cap Replace	Each	300	50	300	300	300	300	0	300	300	300	300
7	Viscous Fan Assy Replace	Each	500	1000	500	500	500	500	800	500	500	500	500
8	Viscous Clutch Assy replace	Each	1000	1000	1000	1000	1000	1000	800	1000	1000	1000	1000
9	Water Pump Assy Replace	Each	1500	1500	1500	1500	1500	1500	1800	1500	1500	1500	1500
10	Water Pump O-Ring Change	Each	1500	1500	1500	1500	1500	1500	800	1500	1500	1500	1500
11	Spacer Fan Replace	Each	1500	1500	1500	1500	1500	1500	800	1500	1500	1500	1500
12	Water Pump Pulley Assy Replace	Each	1500	800	1500	1500	1500	1500	1000	1500	1500	1500	1500
13	Thermostat Case Change	Each	300	300	300	300	300	300	0	300	300	300	300
14	Thermostat Cover Replace	Each	300	300	300	300	300	300	0	300	300	300	300
15	Thermostat Assy Replace	Each	300	300	300	300	300	300	0	300	300	300	300

THE COMPARATIVE STATEMENT OF VEHICLE MAINTENANCE & SPARE PARTTS FOR THE FY 2024-25													
Sl no	Item Decription	Unit	Druk Penden Engineering										
			SKY JACKER TATA 712	BOLERO	SKY JACKER (710BS6)	WATER TANKER [TATA 1010	TATA TIPPER (16.15)	WATER TANKER(T ATA 11.09)	FARM TACTOR (FARMTR	VACCUM TANKER (TATA	VACCUM TANKER (TATA 709)	VACUUM TANKER - EICHER	DCM TRUCK (SML)
16	Radiator Cap Change	Each	50	50	50	50	50	50	50	50	50	50	50
17	Thermostat Case Gasket Change	Each	300	300	300	300	300	300	0	300	300	300	300
18	Thermostat Spacer Change	Each	300	300	300	300	300	300	0	300	300	300	300
(XX)	Break System	NA											
1	Front Break Lining Set Change	Each	500	500	500	500	500	500	0	500	500	500	500
2	Front Break Cam Spring Change	Each	500	500	500	500	500	500	0	500	500	500	500
3	Front Break Return Spring Change	Each	500	500	500	500	500	500	0	500	500	500	500
4	Front Break Bush Kit Change	Each	500	500	500	500	500	500	0	500	500	500	500
5	Front Break Shoe Assy Replace	Each	500	500	500	500	500	500	0	500	500	500	500
6	Rear Break Lining Set Change	Each	500	500	500	500	500	500	0	500	500	500	500
7	Rear Break Cam Spring Change	Each	500	500	500	500	500	500	0	500	500	500	500
8	Rear Breas Return Spring Change	Each	500	500	500	500	500	500	0	500	500	500	500
9	Rear Break Bush Kit Change	Each	500	500	500	500	500	500	0	500	500	500	500
10	Rear Break Shoe Assy Replace	Each	500	500	500	500	500	500	0	500	500	500	500
11	Front Auto Slack Adjuster Replace	Each	300	300	300	300	300	300	0	300	300	300	300
12	Rear Auto Slack Adjuster Replace	Each	300	300	300	300	300	300	0	300	300	300	300
13	Front MSP Repair Kit Change	Each	500	800	500	500	500	500	0	500	500	500	500
14	Front Break Actuator Assy Replace	Each	1000	500	1000	1000	1000	1000	0	1000	1000	1000	1000
15	Rear MSP Repair Kit Change	Each	1000	800	1000	1000	1000	1000	0	1000	1000	1000	1000
16	Rear Break Actuator Assy Replace	Each	1000	500	1000	1000	1000	1000	0	1000	1000	1000	1000
17	Front Outlet Pipe Change	Each	300	300	300	300	300	300	0	300	300	300	300
18	Front Break Hose Pipe Change	Each	300	300	300	300	300	300	0	300	300	300	300
19	Pipe Assy Actuator Inletparking Change	Each	300	300	300	300	300	300	0	300	300	300	300
20	Pipe Assy Actuator Inletservice Change	Each	300	300	300	300	300	300	0	300	300	300	300
21	Air Reservoir Tank Assy Replace	Each	1000	0	1000	1000	1000	1000	0	1000	1000	1000	1000
22	Hand Control Valve Replace	Each	800	0	800	800	800	800	0	800	800	800	800
23	DDU Assy Replace	Each	1500	0	1500	1500	1500	1500	0	1500	1500	1500	1500
24	DDU Kit Change	Each	1500	0	1500	1500	1500	1500	0	1500	1500	1500	1500
25	DDU Pipe 1 Inlet Change	Each	300	0	300	300	300	300	0	300	300	300	300
26	DDU Pipe 2 Inlet Change	Each	300	0	300	300	300	300	0	300	300	300	300
27	DDU Pipe 3 Inlet Change	Each	300	0	300	300	300	300	0	300	300	300	300
28	Dual Break Valve Assy Replace	Each	1000	0	1000	1000	1000	1000	0	1000	1000	1000	1000
29	Dual Break Valve Pipe FR Inlet Change	Each	300	0	300	300	300	300	0	300	300	300	300
30	Dual Break Valve Pipe FR Outlet Change	Each	300	0	300	300	300	300	0	300	300	300	300
31	Dual Break Valve Pipe RR Outlet Change	Each	300	0	300	300	300	300	0	300	300	300	300
32	Dual Break Valve Pipe RR Inlet Change	Each	300	0	300	300	300	300	0	300	300	300	300



THE COMPARATIVE STATEMENT OF VEHICLE MAINTENANCE & SPARE PARTTS FOR THE FY 2024-25													
Sl no	Item Decription	Unit	Druk Penden Engineering										
			SKY JACKER TATA 712	BOLERO	SKY JACKER (710BS6)	WATER TANKER [TATA 1010	TATA TIPPER (16.15)	WATER TANKER(T ATA 11.09)	FARM TACTOR (FARMTR	VACCUM TANKER (TATA	VACCUM TANKER (TATA 709)	VACUUM TANKER - EICHER	DCM TRUCK (SML)
33	Exhaust Break Assy Replace	Each	1500	0	1500	1500	1500	1500	0	1500	1500	1500	1500
34	Exhaust Break Pipe Change	Each	300	0	300	300	300	300	0	300	300	300	300
(XXI)	<b>Inlet &amp; Exhaust System</b>	<b>NA</b>											
1	Air Filter Assy Change	Each	100	100	100	100	100	100	100	100	100	100	100
2	Snorkel Assy Replace	Each	1500	800	1500	1500	1500	1500	0	1500	1500	1500	1500
3	Bellow Air Intake Hose Change	Each	300	800	300	300	300	300	0	300	300	300	300
4	Hose Air Cleaner Outer Change	Each	300	300	300	300	300	300	0	300	300	300	300
5	Air Cleaner Outlet Hose Assy Replace	Each	300	300	300	300	300	300	0	300	300	300	300
6	Air Intake Duct Assy Replace	Each	300	0	300	300	300	300	0	300	300	300	300
7	Intake Manifold Packing Change	Each	800	500	800	800	800	800	0	800	800	800	800
8	Intake Manifold Assy Replace	Each	800	500	800	800	800	800	0	800	800	800	800
9	Turbo Charger Assy Replace	Each	1000	1000	1000	1000	1000	1000	0	1000	1000	1000	1000
10	Turbo Charger Packing Change	Each	1000	1000	1000	1000	1000	1000	0	1000	1000	1000	1000
11	Turbo Pipe Oil Supply Change	Each	300	300	300	300	300	300	0	300	300	300	300
12	Intercooler Assy Replace	Each	1000	500	1000	1000	1000	1000	1000	1000	1000	1000	1000
13	Intercooler Pipe Change	Each	300	300	300	300	300	300	300	300	300	300	300
14	Hose TC Out Change	Each	300	300	300	300	300	300	0	300	300	300	300
15	Intercooler Hose Out Change	Each	300	300	300	300	300	300	300	300	300	300	300
16	Intercooler Hose Inlet Change	Each	300	300	300	300	300	300	300	300	300	300	300
17	Exhaust Center Pipe Assy Replace	Each	500	800	500	500	500	500	0	500	500	500	500
18	Exhaust Pipe Front Change	Each	300	700	300	300	300	300	0	300	300	300	300
19	Exhaust DCO Assy Replace	Each	1000	800	1000	1000	1000	1000	0	1000	1000	1000	1000
20	Exhaust Gasket Change	Each	1000	300	1000	1000	1000	1000	0	1000	1000	1000	1000
21	DOC Gasket Change	Each	1000	300	1000	1000	1000	1000	0	1000	1000	1000	1000
22	Exhaust Muffler Assy Replace	Each	1000	800	1000	1000	1000	1000	1000	1000	1000	1000	1000
23	Exhaust Tail Pipe Assy Replace	Each	1000	800	1000	1000	1000	1000	0	1000	1000	1000	1000
24	Compressor Assy Replace	Each	1500	0	1500	1500	1500	1500	0	1500	1500	1500	1500
25	Compressor Gasket Change	Each	1500	0	1500	1500	1500	1500	0	1500	1500	1500	1500
26	Compressor Major Kit Change	Each	1500	0	1500	1500	1500	1500	0	1500	1500	1500	1500
27	Compressor Minor Kit Ghange	Each	1500	0	1500	1500	1500	1500	0	1500	1500	1500	1500
28	Compressor Piston Change	Each	1500	0	1500	1500	1500	1500	0	1500	1500	1500	1500
29	Compressor Piston Ring Set (STD) Change	Each	1500	0	1500	1500	1500	1500	0	1500	1500	1500	1500
30	Compressor Outlet Pipe Assy Change	Each	300	0	300	300	300	300	0	300	300	300	300
31	Compressor Hose Air Inlet Change	Each	300	0	300	300	300	300	0	300	300	300	300
(XXII)	<b>Fuel System</b>	<b>NA</b>											
1	Fuel Injection Pump Assy Replace	Each	1500	1500	1500	1500	1500	1500	1500	1500	1500	1500	1500
2	Flange Plate Assy Replace	Each	1000	1000	1000	1000	1000	1000	0	1000	1000	1000	1000
3	Pump Gear Change	Each	1000	1000	1000	1000	1000	1000	1500	1000	1000	1000	1000
4	O-Ring Change	Each	1000	1000	1000	1000	1000	1000	1500	1000	1000	1000	1000



THE COMPARATIVE STATEMENT OF VEHICLE MAINTENANCE & SPARE PARTTS FOR THE FY 2024-25													
Sl no	Item Decription	Unit	Druk Penden Engineering										
			SKY JACKER TATA 712	BOLERO	SKY JACKER (710BS6)	WATER TANKER [TATA 1010	TATA TIPPER (16.15)	WATER TANKER(T ATA 11.09)	FARM TACTOR (FARMTR	VACCUM TANKER (TATA	VACCUM TANKER (TATA 709)	VACUUM TANKER - EICHER	DCM TRUCK (SML)
21	Starte coil Change	Each	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000
22	Ignition switch Change	Each	300	1000	300	300	300	300	1000	300	300	300	300
23	Starter relay 12v Change	Each	200	200	200	200	200	200	1000	200	200	200	200
24	Relay 5 pin 12v Change	Each	200	200	200	200	200	200	200	200	200	200	200
25	Relay 4 pin 12v Change	Each	200	200	200	200	200	200	200	200	200	200	200
26	Relay 3 pin 12v Change	Each	200	200	200	200	200	200	200	200	200	200	200
27	Relay 2 pin 12v Change	Each	200	200	200	200	200	200	200	200	200	200	200
28	Electric horn 2v Change & Repair	Each	500	400	500	500	500	500	400	500	500	500	500
29	Musical horn 12v New Fitting	Each	500	400	500	500	500	500	400	500	500	500	500
30	Horn Assy Replace	Each	500	400	500	500	500	500	400	200	500	500	500
31	Horn relay Change	Each	200	200	200	200	200	200	400	10	200	200	200
32	Fuse 30 Amp Change	Each	10	20	10	10	10	10	20	10	10	10	10
33	Fuse 25 Amp Change	Each	10	20	10	10	10	10	20	10	10	10	10
34	Fuse 20 Amp Change	Each	10	20	10	10	10	10	20	10	10	10	10
35	Fuse 15 Amp Change	Each	10	20	10	10	10	10	20	10	10	10	10
36	Fuse 10 Amp Change	Each	10	20	10	10	10	10	20	10	10	10	10
37	Fuse 5 Amp Change	Each	10	20	10	10	10	10	20	10	10	10	10
38	Glow plug Change	Each	20	100	0	10	10	10	100	100	10	10	10
39	Head light buldb (Halogen) Change	Each	100	100	100	100	100	100	100	20	100	100	100
40	Bulb 1141 Change	Each	20	20	20	20	20	20	20	20	20	20	20
41	Bulb 67 change	Each	20	20	20	20	20	20	20	20	20	20	20
42	Side Light Assy	Each	200	100	200	200	200	200	200	200	200	200	200
43	Back light Assy (Left) Repair/Replace	Each	200	200	200	200	200	200	200	200	200	200	200
44	Back light Assy (Right) Repair/Replace	Each	200	200	200	200	200	200	200	200	200	200	200
45	Head light Assy (Left) Replace	Each	200	300	200	200	200	200	200	200	200	200	200
46	Head light Assy (Right) Replace	Each	200	300	200	200	200	200	200	200	200	200	200
47	Cluster meter Assy Replace	Each	1500	1500	1500	1500	1500	1500	1000	1500	1500	1500	1500
48	Killo Meter cable Change	Each	300	300	300	300	300	300	300	300	300	300	300
49	Hour meter Replace/Repair	Each	300	300	300	300	300	300	300	300	300	300	300
50	Speedo meter pinion Change	Each	300	500	300	300	300	300	300	300	300	300	300
51	Engine mounting Change	Each	500	500	500	500	500	500	0	500	500	500	500
52	Brake light switch Change	Each	200	100	200	200	200	200	100	200	200	200	200
53	Wiper blade Assy Replace	Each	50	50	50	50	50	50	0	50	50	50	50
54	Wiper motor Assy Replace	Each	1500	1000	1500	1500	1500	1500	0	1500	1500	1500	1500
55	Dynamo rocker Change	Each	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000
56	Starter Motor Assy Replace	Each	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000
57	Combination Switch Assy Replace/Repair	Each	1000	1000	1000	1000	1000	1000	500	1000	1000	1000	1000
58	Starter Switch Assy Replace	Each	1000	300	1000	1000	1000	1000	500	1000	1000	1000	1000

THE COMPARATIVE STATEMENT OF VEHICLE MAINTENANCE & SPARE PARTTS FOR THE FY 2024-25													
Sl no	Item Decription	Unit	Druk Penden Engineering										
			SKY JACKER TATA 712	BOLERO	SKY JACKER (710BS6)	WATER TANKER [TATA 1010	TATA TIPPER (16.15)	WATER TANKER(T ATA 11.09)	FARM TACTOR (FARMTR	VACCUM TANKER (TATA	VACCUM TANKER (TATA 709)	VACUUM TANKER - EICHER	DCM TRUCK (SML)
59	Wiper Link Rod Assy Replace	Each	600	600	600	600	600	600	0	600	600	600	600
60	Wiper Arm Assy Replace	Each	100	200	100	100	100	100	0	100	100	100	100
61	Vehicle Regenration Charges for BS VI	Each	3000	0	3000	3000	3000	3000	0	3000	3000	3000	3000
62	Software updateing Charges for BS VI	Each	30000	0	30000	30000	30000	30000	0	30000	30000	30000	30000
63	Battery Charging	Each	500	300	500	500	500	500	500	500	500	500	500
(XXV)	<b>Door &amp; Window</b>	<b>NA</b>											
1	Regulator Assy Replace	Each	50	500	600	50	800	50	0	50	800	50	50
2	Door Handle Outer Assy Change	Each	300	300	300	300	300	300	0	300	50	300	300
3	Door Handle Inner Change	Each	300	300	300	300	300	300	0	300	300	300	300
4	Door Pad Change	Each	500	300	500	500	500	500	0	500	500	500	500
5	Regulator Handle Assy Change	Each	50	50	50	50	50	50	0	50	50	50	50
6	Door Glass Replace	Each	500	600	500	500	500	500	0	500	500	500	500
7	Wind Shild Glass Replace	Each	1500	1500	1500	1500	1500	1500	0	1500	1500	1500	1500
8	Weather Strip Inner/Outer Change	Each	500	1000	500	500	500	500	0	500	500	500	500
9	Door Inner Handle Assy Change	Each	300	300	300	300	300	300	0	300	300	300	300
10	Door Latch Assy Change	Each	300	300	300	300	300	300	0	300	300	300	300
11	Door Rod Inside Lock Change	Each	300	300	300	300	300	300	0	300	300	300	300
12	KNOB Inside Lock Change	Each	100	50	100	100	100	100	0	100	100	100	100
13	Stricker Plate Change	Each	200	200	200	200	200	200	0	200	200	200	200